



# **MECHANICAL ENGINEERING PROJECT I**

**ÇUKUROVA UNIVERSITY  
DEPARTMENT OF MECHANICAL ENGINEERING**

**BURAK YÖRÜKÇÜ**

**PROJECT TITLE:** Pneumatic Tube Transfer System Automation

**PROJECT SUPERVISOR:** Prof.Dr. NECDET GEREN

**SUBMISSION DATE:** 26.01.2024

# Table of Contents

- LIST OF FIGURES
- LIST OF TABLES
- LIST OF CHARTS
- PROBLEM DEFINITION
  - Aim of the Project
  - Design Considerations
  - Project Planning
- CONCEPT GENERATION
  - Concept Designs
  - Concept Design A
  - Concept Design B
  - Concept Design C
  - Concept Selection
  - Weighted Decision Matrix
- DEVELOPMENT OF THE DESIGN
  - Schematic Layout
  - Program Flow Chart
  - Series Function Chart
  - Step-counter Chart
  - Direct Control Valve Inputs
  - Designing of Station
  - Design of Carriers
  - Sizing of the Actuators
  - Selection of the Conveyors
  - List of Equipment
  - Selecting of Actuators
  - Air Consumption for Actuators
- COMMENTS AND CONCLUSION
- REFERENCES

# List of Figures




Fig. 3-26 Actuator sizing nomogram.

fig 3-26.

# Aim of the Project

Pneumatic tube systems are a type of material handling system that uses compressed air to transport carriers through a network of tubes. These systems are commonly used in hospitals, banks, and other facilities where there is a need for rapid and efficient transport of small items. A significant limitation of pneumatic tube systems is that they are not fully automatic. However, my project aims to be the solution for this issue. The main aim of this project is to remove the need for human intervention in pneumatic tube systems as a conclusion of this elimination pneumatic tube systems will work much more efficient and achieve greater stability.

# Design Considerations

This project proposes a novel design for pneumatic tube systems specifically tailored for transporting medical samples. With the primary objective of aiding medical staff, the design prioritizes:

**Enhanced Efficiency:** Compared to manual transport, the system boasts significantly faster delivery times, minimizing sample exposure and expediting critical medical processes.

**Minimized Risk of Damage:** The design ensures safe and secure transport, eliminating potential harm to sensitive samples caused by human error or environmental factors.

**Reduced Error Potential:** Automated operation eliminates the risk of confusion among samples, guaranteeing accurate delivery to the designated destination.

Beyond these core objectives, the design excels in its user-friendliness and safety:

**Intuitive Usability:** Designed for near-complete automation, the system requires minimal user interaction and can be operated safely and effectively even under pressure.

**Emergency Stopping Mechanism:** Equipped with an easily accessible stop button, the system can be safely halted in case of unforeseen circumstances, ensuring sample integrity remains uncompromised.

Material selection focuses on optimal performance and sample protection:

**Carrier:** Borosilicate glass, chosen for its exceptional thermal shock resistance and low coefficient of thermal expansion, safeguards samples against temperature fluctuations. Additionally, the outer shell utilizes high-strength polyurethane, offering excellent impact resistance and low density for efficient transport.

**Tube System:** Cost-effective and readily available, PVC serves as the perfect material for the tubing network, ensuring leak-proof operation and ease of installation.

Safety remains paramount throughout the design, employing minimal forces that pose no risk to users or samples. While aesthetics are considered less significant given the typically concealed nature of tube systems within walls, the overall design prioritizes functionality and reliability.


In conclusion, this project presents a well-considered pneumatic tube system design optimized for medical sample transport. By prioritizing efficiency, safety, and user-friendliness, the proposed system holds significant potential to streamline medical operations and ensure the integrity of critical samples.

# Project Planning


[illegible]

# Concept Generation

## Concept A




## Concept B





## Concept C




Weighted Decision Matrix

WEIGHTED DECISION MATRIX TEMPLATE											
Prioritization Criteria		Value	Concept A		Score	Concept B		Score	Concept C		Score
Number of Parts		0.2	6		1.2	8		1.6	7		1.4
Ease of Manufacture		0.2	10		2	6		1.2	7		1.4
Cost		0.3	10		3	8		2.4	9		2.7
Applicability		0.2	7		1.4	3		0.6	5		1
Weight		0.1	5		0.5	8		0.8	7		0.7
Total		1	38		8.1	33		6.6	35		7.2


## Development of Design

### Schematic Layout



Description	Function
Actuator A	Slowly pushing down the moving station to conveyor and gripping the conveyor
Actuator B	Slowly pushing down the moving station to conveyor and gripping the conveyor but working contrary with actuator A
Actuator C	Slowly pushing down the moving station to conveyor and gripping the conveyor
Actuator D	Slowly pushing down the moving station to conveyor and gripping the conveyor but working contrary with actuator C
Actuator E	Slowly pushing down the moving station to conveyor and gripping the conveyor
Actuator F	Slowly pushing down the moving station to conveyor and gripping the conveyor but working contrary with actuator E

## Program Flow Chart




## Series Function Chart

b0	x1	_____
b1	x1	_____
e0	x1	_____
e1	x1	_____
ST.	x1	Program2.b0.Start

a0	x1	_____
a1	x1	_____
d1	x1	_____
d0	x1	_____
ST.	x1	Program1.a0.Start

c0	x1	_____
c1	x1	_____
f0	x1	_____
f1	x1	_____
ST.	x1	Program3.c0.Start

Step-Counter Chart



## Direct Control Valve Inputs


DCV(power valve) Inputs		
A1	Step1	
A0	Step4	
D1	Step2	Program1
D0	Step3	
B1	Step1	
B0	Step4	
E1	Step2	Program2
E0	Step3	
C1	Step1	
C0	Step4	Program3
F1	Step2	
F0	Step3	

## Step-counter Inputs

Step-counter inputs	
Stepping Module 1	a0.Start.Program1
Stepping Module 2	a1
Stepping Module 3	d1
Stepping Module 4	d0
Stepping Module 1	b0.Start.Program2
Stepping Module 2	b1
Stepping Module 3	e1
Stepping Module 4	e0
Stepping Module 1	c0.Start.Program3
Stepping Module 2	c1
Stepping Module 3	f1
Stepping Module 4	f0

## Sizing of the Actuators

For all actuators my calculation is same because all actuators carry the same weight and repeating same motions. For actuator A=B=C=D E=F.



$$V = \frac{S}{t} = \frac{0.05}{1} = \frac{0.05m}{s}$$

$$S = \frac{V^2}{2a} = a = \frac{(0.05)^2}{2 \times (0.025)} = \frac{0.05m}{s^2}$$

My station weight is 7.76 kilogram but for safety purposes i choose my weight as 8 kilogram

$$Fl = mxg = 8 \times 9.81 = 78.48N$$



$$F_m = mxa = 8 \times 0.05 = 0.4N$$

$$F_t = F_l + F_m = 78.88N$$

$$nd = 3$$

$$F_d = 3 \times 78.88 = 236.64N$$

Using curve C from fig 3-26.

Diameter is 25mm.

## Air Consumption for Actuators

$$Q = (101,3 + \frac{P}{101,3}) \times d^2 \times 0,7854 \times S$$

$$Qv = (101,3 + \frac{600}{101,3}) \times 0,08^2 \times 0,7854 \times 0,1 \times 30$$

$$Qv = \frac{0,1043966m^3}{minute}$$

$$Q_{total} = 0,1043966 \times 6 = \frac{0,62637986m^3}{minute}$$

## Selecting of Actuators


According to our calculations I selected DSNU piston with 25mm diameter because relatively cheaper than the other DSNU pistons and enough to for our application. My all actuators will be same because all of them carrying same weight and same direction with constant speed.

### Datasheet

Speed [mm/s] <sup>1)</sup>	16	20	25	32	40	50	63
Piston ø							
Speed with stick-slip-free operation, S10 horizontal, without load, at 0.6 MPa (6 bar)	10 ... 100			8 ... 100			5 ... 100

Forces [N] and impact energy [J]	8	10	12	16	20	25	32	40	50	63
Piston ø										
Theoretical force at 0.6 MPa (6 bar), advancing	30	47	68	121	189	295	483	753	1178	1870
Theoretical force at 0.6 MPa (6 bar), retracting	23	40	51	104	158	247	415	633	990	1682
Impact energy in the end positions for P cushioning <sup>1)</sup>	0.03	0.05	0.07	0.15	0.20	0.30	0.40	0.70	1.00	1.30

#### Piston ø 25




- DSNU-25-50
- DSNU-25-100
- - - DSNU-25-200

# Datasheet

## Materials


Sectional view




Round cylinder	8 ... 25	32 ... 63
[1] Piston rod		
DSNU-...	High-alloy steel	
DSNU-...-R3	High-alloy stainless steel	
DSNU-...-A6	–	Hard-chrome-plated tempered steel
[2] Piston rod bearing	Sintered bronze	
[3] Bearing cap	Colourless anodised wrought aluminium alloy	
[4] Cylinder barrel	High-alloy stainless steel	
[5] End cap	Colourless anodised wrought aluminium alloy	
[6] Swivel bearing	Polymer	
– Seals		
DSNU ...	TPE U(PU), NBR	
DSNU-...-S6	FPM	
DSNU-...-S10/-L	FPM	FPM, TPE-U(PU)
DSNU-...-R3	TPE-U (PUR) media seal (modified for resistance to hydrolysis and cleaning)	
Piston rod scraper		
DSNU-...-A6	–	CuZn
PWIS conformity	VDMA24364-B1/B2-L <sup>1)</sup>	
Cleanroom class	Class 6 according to ISO 14644-1	
Note on materials		
DSNU-...	RoHS-compliant	
DSNU-...-S10	Contains paint-wetting impairment substances	
DSNU-...-F1A	Metals with more than 1% copper, zinc or nickel by mass are excluded from use. Exceptions are nickel in steel, chemically nickel-plated surfaces, printed circuit boards, cables, electrical plug connectors and coils	

# Datasheet


P cushioning



PPV cushioning



PPS cushioning



$\varnothing$  - Diameter  
8 ... 25 mm  
ISO 6432

$\varnothing$  - Diameter  
32 ... 63 mm

- Stroke length  
1 ... 500 mm,  
longer strokes on request



## General technical data


Piston ø	8	10	12	16	20	25	32	40	50	63
Conforms to standard	ISO 6432						–			
Pneumatic connection	M5	M5	M5	M5	G1/8	G1/8	G1/8	G1/4	G1/4	G3/8
Piston rod thread	M4	M4	M6	M6	M8	M10x1.25	M10x1.25	M12x1.25	M16x1.5	M16x1.5
Stroke <sup>1)</sup> [mm]	1 ... 100		1 ... 200		1 ... 320	1 ... 500				
Design	Piston/piston rod/cylinder barrel									
Cushioning										
DSNU-...-P	Elastic cushioning rings/pads at both ends									
DSNU-...-PPV	–		Cushioning, adjustable at both ends							
DSNU-...-PPS	–			Cushioning, self-adjusting at both ends						
Cushioning length										
DSNU-...-PPV [mm]	–		9	12	15	17	14	18	20	21
DSNU-...-PPS [mm]	–			12	15	17	14	18	20	21
Position sensing	Via proximity switch									
Type of mounting	Direct mounting (variant MH only)									
	With accessories									
Mounting position	Any									

<sup>1)</sup> Cylinders with position sensing require a minimum stroke of 10 mm to ensure reliable sensing.  
Longer strokes on request

## Sizing of the Station

$$20 \times 20 \times 20 = 8000 \text{ cm}^3$$

$$\frac{8000 \text{ cm}^3 \times 0.97 \text{ g}}{\text{cm}^3} = 7760 \text{ g} = 7.76 \text{ kg}$$




Material of station is PE because PE is lightweight, flexible, durable and strong as well as friction resistance especially Ultra-high-molecular-weight polyethylene (UHMW-PE) is perfect for our station thanks to excellent abrasion and wear resistance.

## Sizing of the Carriers


For blood carrier:

$$15 \times 3 \times 1.5 = 67.5g$$



For urine carrier:

$$12 \times 2 \times 5 = 120g$$



For main material of the carrier is polyurethane because polyurethane has good tensile strength, impact strength high melting point as well as low density compared to the other choices also polyurethane is very cheap so this is best material for our application.

Overall diameter for blood carrier:

$$13 \times 15 = 195mm$$

Overall diameter for urine carrier:

$$12 \times 16 = 192mm$$

Our carrier diameter has to be around 200mm.

$$V = \pi r^2 h = \pi \times 10^2 \times 10 = 3141.59cm^3$$

$$\frac{3141.59cm^3 \times 1.2g}{cm^3} = 3769.91g$$

$$3769.91 + 67.5 = 3837.61g \text{ for blood carrier}$$

$$3769.91 + 120 = 3889.91g \text{ for urine carrier}$$

## List of Equipments

[illegible]



## Selecting of the Conveyors

In this project we don't have to deal with high speed or high loads, weights so our conveyor it should be long enough to reach all stations as well as should be cheap to be considered among other conveyors. D-Series Conveyors from Redline System Inc features perfect for our aim.

The D-Series line of material handling conveyor belts are second cousins to the SD-Series. The D-Series is used when you need to move your material along a horizontal plane or slight incline. If you need to get stuff from point A to point B, the D-Series may be just the ticket.

The bed of this industrial material handling conveyor belt is constructed with a 20 degree trough configuration. This is designed to prevent material from rolling off the belt during transit. The belt is supported by a center roller for additional strength. Bed widths are built in 16, 10, and 24 inch dimensions so that you can match the conveyor to your material throughput requirements. The bearings on the belt pulleys are sealed and pre-lubricated.

# Specifications

---

## D-Series Conveyor Features

- **Bed**– 16" 20", or 24" wide troughed bed.
- **Frame**: Strong, Rugged Truss style welded frame.
- **Belt**: 2 ply 150 black Rubber.
- **Drive**: Electric, gas, or hydraulic motor available.
- **Bearings**– Sealed, pre-lubricated, self-aligning, ball bearings.
- **Drive pulley**– 7" in diameter. Open caged for self-cleaning.
- **Tail Pulley**– 6" in diameter. Open caged for self-cleaning.



## Selecting of Blower

For this application we need at least  $0.62 \frac{m^3}{minute}$  blower and we should keep our blower around this number because if we exceed too much our blood samples will be exposed to shear stress due to shear stress blood sample results will not be true due to this issue I choose SANYO DENKI 109BF24HA2 Centrifugal blower.

High air flow and high static pressure  
Low power consumption  
PWM control function  
40000 hours at 60°C expected life



## Product Information

<input type="checkbox"/> Blower Type:	Centrifugal	<input type="checkbox"/> Air Flow - m3/min:	0.78m³/min
<input type="checkbox"/> Supply Voltage:	24VDC	<input type="checkbox"/> Flow Rate - Imperial:	27.5CFM
<input type="checkbox"/> Voltage Type:	DC	<input type="checkbox"/> Noise Rating:	52dBA
<input type="checkbox"/> Fan Frame Size:	120mm	<input type="checkbox"/> Bearing Type:	Ball Bearing
<input type="checkbox"/> External Depth:	32mm	<input type="checkbox"/> Power Connection Type:	2 Lead Wires
<input type="checkbox"/> Flow Rate - Metric:	0.78m³/min	<input type="checkbox"/> Power Rating:	7.2W
<input type="checkbox"/> Air Flow - CFM:	27.5CFM	<input type="checkbox"/> Product Range:	Scircoco Ace 120
		<input type="checkbox"/> IP Rating:	-

## Selecting of Pressure Control Valve

Proportional pressure control valve VPPM is perfect for our needs because of pilot actuated pressure regulating valve and also three default presets for fast commissioning features recover us select 3 different pressure control valve.

Innovative

Flexible

Operational Safety

Easy to Install



- Pilot actuated pressure regulating valve
- Multi-sensor control (cascade control)
- Three default presets for fast commissioning
- Integration in valve manifold MPA
- User interface with LED displays, LCD display, adjustment/selection buttons
- Integrated pressure sensor
- Electrical connection via plug, round design, 8-pin, M12 or manifold linking

## Comments and Conclusion

In this project I aimed that eliminate the human factor in pneumatic tube systems. With elimination of the human factor, we can get our blood,urine tests feedback with little delay as well as carrying serum with this system with fully automatically reduces work load for nurses.

To make this project more efficient we can use CFD analysis to optimise pneumatic tube angles also we need a conveyor to achieve this project that mean is we need more available space to place conveyor and unfortunately this is not possible for many hospitals but in the future with some optimizations we can easily use this fully automatic pneumatic tube system for any hospitals.

According to me, this project will be very useful for big hospitals. In Turkey we have lots of big hospitals and we are waiting for queue too long as well as to get our test results this project may be the solution for to reduce test result time also reduce nurses work load with this nurses can take care of more patient in hospitals.

## References

HOGGE Donna” The Effects of Sample Transport by Pneumatic Tube System on Routine Hematology and Coagulation Tests” Revised 2018 Apr 1

Wojciech Poznanski, M.D., Frances Smith, M.D., Ph.D., Frank Bodley, Ph.D. American Journal of Clinical Pathology, Volume 70, Issue 2, 1 August 1978, Pages 291–295

MILLS David Pneumatic Conveying Design Guide, p. 25 1990.

Kosugi S 2001 Pneumatic capsule pipelines in Japan and future developments (Handbook of Powder Technology) 10 505-11 Dec 31

Vance L and Mattson P 1994 Tube Transportation. US Dept. of Transportation Volpe National Transportation Systems Centre FebFeb

Newton R, Redberger PJ and Round GF 1963 Numerical analysis of some variables determining free flow Can. J. Chem. Eng. 42 168-73

HMSO 2009 Health Technical Memorandum (London) March 2013

Swisslog Rohrho stsysteme GmbH 2014 Pneumatic Tube Systems Intelligent Solutions for Hospital (Germany)

Keshgegian AA and Bull GE 1992 Evaluation of a soft-handling computerized pneumatic tube specimen delivery system: effects on analytical results and turnaround time American journal of clinical pathology 97 535-40 Apr 1

Tanley PC, Wallas CH, Abram MC and Richardson LD 1987 Use of a pneumatic tube system for delivery of blood bank products and specimens Transfusion 27 196-8 Mar 4

Liu HE 2000 Pneumatic Capsule Pipeline Basic Concept, Practical Considerations, and Current Research InProceedings of Mid-Continent Transportation Symposium

Christopher W Farnsworth, Daniel M Webber, James A Krekeler, Melissa M Budelier, Nancy L Bartlett, Ann M Gronowski Parameters for Validating a Hospital Pneumatic Tube System Clinical Chemistry, Volume 65, Issue 5, 1 May 2019, Pages 694–702,

## Appendix